

Main Layout Screen with Set-Up & Options Tab Selected

# Tabs on the Main Layout Screen

## Add Patterns tab

Selecting this button will gray out all other buttons until you click to place the pattern on the Layout Screen

Pattern Selection List

Pattern Display Window

Copyright & Special Instructions

Selected Pattern Display

Add Remove Continuous

Wizards Fonts, Drawing & Light Table File & Print Layout & Design Set-up & Options

## Layout & Design tab

Pass/Pattern Mode Affects Available Active Buttons

Configure Editing Guidelines

Repeat Pass Spacing (Inches) 0.00

Pass Editor Move Pass to Patterns Delete

Width (%) Length (%) 100.0 100.0

Width (in) Length (in) 0.00 0.00

Offset X (in) Offset Y (in) 0.00 0.00

Rotate (Deg) 0.0

Maintain Aspect Ratio

PASSES Mode Selected Pass Orientation ABC

Sewing order for selected pass

Insert Pattern Continuous

Selected Pattern

File & Print Layout & Design

Wizards Fonts, Drawing & Light Table File & Print Layout & Design

Selecting this button will gray out all other buttons until you click to place the pattern on the Layout Screen

Selected Pattern Display

Pattern Selection List

## File & Print tab

Print Marking Guide Print Overview

Save New Load

Load or Save your \*.PQD files

Area changes to accommodate options for selected file format

Add your text comments here

Include a pattern size comment? Include your copyright notice?

Set Speed? Set Stitch/inch?

File Format PC Quilter (\*.txt) No Courtesy Jump Courtesy Jump Options

Orientation Pass File from Pass Create

File & Print Layout & Design

Wizards Fonts, Drawing & Light Table File & Print Layout & Design

Interactive help with selected file format

## Fonts, Drawing & Light Table tab

Mouse Position W 0.46 L -1.43

Quilt with Fonts! Type your Text here > Selected Font No Font Selected! Options

Drawing & Tracing Line Colour Linetype Thin Draw Mode Options


Use right-click to display addition menu selections

Use Ctrl-V to paste the clipboard into the Light Table

Image Zoom Image lock


Light Table Load Image (All graphic formats)

Wizards Fonts, Drawing & Light Table File & Print




Editor Screen (Edit Mode) with AutoTRIM, PAUSE & SMOOTH Tab Selected

**Add, Delete Points, Jumps & Pauses tab**  
 \*NOTE- This illustrates the Editor Screen in PASS EDITOR MODE. In PATTERN EDITOR MODE the "Clip at Guidelines" button becomes "Re-Origin Point to 0,0"




**Echo Quilting tab.**  
 Echo Type is Inside, Outside or Both.  
 NOTE - Compound objects are not supported. This is for simple echoes only.



## Editor Screen Tabs (Pass/Pattern Editor Mode)

© 2007 Quilting Mouse Technologies.

Click on the pictures for more options such as changing the direction of flip, skew or wreath. Clicking the Rotate around the Origin button allows you to create "snowflake style" continuously sewn patterns.



**Edit Jumps tab**  
 When multiple points are selected on a pattern, the "Change Direction All" button becomes "Change Direction Selected" to allow you to selectively reverse sewing.

